

Meyer TIMBER®



meyCHOICE

Pre-Primed Mouldings & Architraves

PRODUCT GUIDE

Meyer 
TIMBER
Victoria

Meyer 
TIMBER
New South Wales

Meyer 
TIMBER
Queensland

Meyer 
TIMBER
Tasmania

www.meyertimber.com.au

meyCHOICE pre-primed mouldings & architraves are designed to be used in a variety of internal applications. To ensure long-term performance it is important to have an understanding of both the product and the installation process.

ON SITE STORAGE AND HANDLING

On site storage should be on timber gluts with at least 150mm clearance from the ground in a dry, well-ventilated area. It is recommended to leave the plastic wrapping from the pack in place, however the pack must be protected from direct sunlight to avoid sweating under the plastic. If meyCHOICE is delivered without wrapping or with damaged wrapping, cover with plastic, sheet material or building paper that is firmly held in place to keep the product clean and dry from the elements. Care must be taken to ensure that the protection of the product doesn't unintentionally collect pools of water that can soak into the timber. Other building products should not be stored on top of meyCHOICE pre-primed mouldings & architraves.

PRIOR TO INSTALLATION

- Ensure that all dirt, dust or any contaminants are cleaned from the surface of the board.
- Any bare timber areas exposed through cutting or notching must be re-primed prior to installation with a good quality primer.
- Sand any uneven surfaces for a premium finish.
- meyCHOICE pre-primed mouldings & architraves are generally supplied to the site with a moisture content of approximately 12% (+/- 2%). At the time of installation, meyCHOICE must have a moisture content close to the local expected average ambient moisture content. For sites where the ambient moisture content is significantly different, some acclimatisation may be required prior to installation.
- Prior to painting, make sure that the surface of the primer is not chalky and that the primer adhesion is good. The 'X' test can / be used to check this. Use a sharp blade to cut an X into the existing paint coatings. Then place a piece of sticky tape over the X and press down firmly. Quickly peel the tape off the surface. Repeat the process in different areas to check the entire surface. If flakes of paint are stuck to the sticky tape, or have flaked away from the test surface, the current coating should not be painted over. The paint should be removed by sanding or stripping the surface back and treating the area as a new, unpainted surface. If there is no paint on the tape, and no paint has flaked from the test areas, your surface can be repainted.

It is recommended that at least one coat (preferably two) of a premium interior grade topcoat paint colour matched to the final finishing coat is applied all around the board prior to fixing. By doing so, this will significantly reduce the moisture loss or uptake from all surfaces of the boards

CUTTING INSTRUCTIONS

meyCHOICE pre-primed mouldings & architraves should be cut from the moulded face through to the backface. This will help prevent fibre tear from occurring which will damage the appearance of the product.

When chiselling or routing, please ensure that sharp and well-maintained tools are used. This will help ensure that a clean finish is maintained.

TOPCOATS

It is recommended that at least two topcoats of paint be applied after fixing in accordance with the paint manufacturer's recommendations. The minimum paint film requirements can be found on the tin.


MAINTENANCE

The long-term performance of meyCHOICE pre-primed mouldings & architraves is dependent on regular and effective maintenance. The frequency of maintenance will depend on the type of paint used. Before re-coating, the meyCHOICE product should be cleaned and the joints resealed where required. Any re-coating should be carried out in accordance with the paint manufacturer's recommendations.


WARRANTY

To maintain the limited guarantee offered by suppliers, details pertaining to the products used on the project must be kept.


PROFILE RANGE




COLONIAL




PENCIL ROUND



321 LINING




HALF SPLAY




BULLNOSE




302 LINING



BEVEL



DAR



DOOR JAMB



LINING BOARD
INSTALLATION GUIDE



WEBSITE



Meyer TIMBER®

Meyer 
TIMBER
Victoria

Meyer 
TIMBER
New South Wales

Meyer 
TIMBER
Queensland

Meyer 
TIMBER
Tasmania

www.meyertimber.com.au